

INSTALLATION INSTRUCTIONS

Parts Included

- 1 Valve Body • 1 Hose • 1 Cradle • 1 Elephant Spout • 3 Washers • 2 Cone Washers • 2 Plated Locknuts • 2 Connecting Nuts • 2 (2 1/4") Threaded Nipples • 60" Riser • 6" Wall Support • 1 Sunflower Showerhead

Tools Needed

- Adjustable Wrench • Slip Joint Pliers • Pipe Putty or Teflon Pipe Tape •
• 2 Mounting Flanges Needed • Offset Bath Supplies **#5577** •

NOTE: If Handles are identified HOT and COLD. The hot handle must be to the left and cold to the right. Be sure the water supply is turned off before starting installation. Cushion the wrench or slip joint pliers with an old cloth to protect the finish of the fixture.

To Install Faucet

1. Turn off water
2. Align the valve assembly with the mounting flanges and secure with the nuts on the mounting flanges. Tighten with a wrench or pliers. **NOTE:** Flanges may be positioned up or down, depending on how high you want the spout.
3. Apply teflon tape to both ends of the hot and cold supply nipples. Thread the tapered ends of the nipples into the mounting flanges. On the outside of the tub, thread the large locknuts onto the other ends of the nipples and secure the shower set to the tub.
4. Thread diverter valve onto valve assembly.
5. Slip the wall bracket over the straight end of the riser pipe. Carefully slide the bracket to the appropriate position (approximately half-way up the rod) and tighten the set screw provided.
6. Position cradle bracket on riser. Tighten with set screw.
7. Assemble riser pipe to the riser coupling assembly on the spout by tightening the coupling nut. After hand tightening, fasten securely by using a wrench.
8. Secure wall support bracket to the wall using the screws provided with part **#4195WS**.
9. Install washers in the hose ends and attach the hose to the cradle and hand shower. (DO NOT over tighten)
10. Screw showerhead onto riser.



To Connect Shower Set to Straight Bathh Supplies #5577

1. Put the cone washers on the tub and connect the end of each water supply tube. Then slide the 1/2" connecting nuts over the opposite ends of the supply tubes and up to the cone washers.
2. Twist the connecting nuts over the cone washers and thread the nuts onto the nipples.
3. Connect the other ends of the brass water supply tubes to your house water lines. Consult your local plumber for assistance.
4. Repeat steps 1-3 using the right supply tube.

NOTE: Please seek professional help if you have copper plumbing in your home.

Cleaning Instructions

Wipe this whole set off with warm water and a soft cloth. DO NOT use soaps, cleansers, or brass cleaners as they will disintegrate the protective lacquer coating and leave the brass exposed causing it to tarnish.