

# SH-10-72, SH-10-C2

## Handshower Supply Elbow Installation Instructions

**CALIFORNIA FAUCETS RECOMMENDS THAT ALL PLUMBING PRODUCTS BE INSTALLED BY A LICENSED PROFESSIONAL**

**IMPORTANT:** Read all instructions prior to installation and provide copy of instructions to consumer.

### I INSTALLING SUPPLY ELBOW

**Note:** Following is to be done when finished wall is completed.

- Hole opening shall be Maximum  $\varnothing 1-1/4"$
- Apply 3 wraps of Teflon® TAPE (1) on appropriated length  $1/2"$  NPT NIPPLE (2) threads and thread into ADAPTER (3)
- Apply 3 wraps of Teflon® TAPE (1) to other end of  $1/2"$  NPT NIPPLE (2) and insert through finished wall opening
- Use  $5/8"$  deep socket and tighten ADAPTER (3) until adapter hex surface is flush with finished wall as shown in diagram
- Tip of ADAPTER (3) should stick out  $9/16"$  to  $5/8"$  from finished wall surface
- Attach ELBOW (4) onto ADAPTER (3) and tighten SETSCREW (5) with hex KEY (6)

