



CATALOGUE DESCRIPTION	C. P. push ring in line divertor mechanism for C. P. brass Pillar and Deck type bath shower mixers.
DISMANTLING & REASSEMBLY	Unscrew shower attachment.     Unscrew divertor assembly which should be hand tight.     Remove washer plate assembly and spring from body.     Reassemble in reverse order.
SERVICING	DIVERTOR WILL NOT HOLD IN SHOWER POSITION. a) Insufficient head of water (pressure) e.g. Flomatic installation. Change spring 040118 to light spring 04388 see diagram. b) Obstruction – foreign matter in mechanism or wear on divertor washer. Dismantle and clean or replace where necessary see above.  WATER EMANATES FROM NOZZLE AND SHOWER AT THE SAME TIME Obstruction – foreign matter in mechanism or wear on divertor washer. Dismantle and clean or replace where necessary see above.