

### **Features**

- 25" (635) x 22" (559) x 7" (178) top mount kitchen sink.
  Single compartment.
- 20 gauge 304 stainless steel.Center drain location.
- Brushed finish.
- Superior undercoating for added sound insulation.
- 3mm sound deadening pads on all 4 sink sides and bottom. Up to 3 times heavier than competitive models.
- Fits 30" base cabinet width.

### Components

Product includes: **Cutout Template** Installation Hardware Installation Instructions

### **Options**

TSGC25221 Stainless Steel Bottom Sink Grid TCBC1116 Bamboo Cutting Board 2210R Covered Sink Strainer 4010 Covered Disposer Strainer

### Warranty

Lifetime Limited Warranty

## **Specified Model**

Model	STSB25227
Overall	L25" x W221/64" x D7"
Dimensions	635 x 559 x 178
Bowl Dimensions	L20 <sup>6</sup> 3/ <sub>4</sub> " x W15 <sup>33</sup> / <sub>4</sub> " x D7" 533 x 394 x 178
Drain hole:	35/8" (92mm)
Shipping Weight	14 lbs.
Material	20 gauge 304 stainless steel
Installation	counter top mounted
Required	template, included

### To Be Specified:

see back for configurations available for this sink

Faucet Hole Drillings
1 Hole
2 Holes - MR2
3 Holes
4 Holes
5 Holes


## Codes/Standards

ASME A112.19.3/CSA B45.4

## **Notes**


Install this product according to the installation instructions.








## Faucet Hole Configurations available for this sink model



## **Optional Accessories**

### TSGC25221 Bottom Sink Grid




### 2210R Covered Flip Top Sink Strainer.




Water drains easily when cover is in place. Cover flips up with easy touch. Cover makes a flat surface at the sink bottom that prevents food waste from getting into the strainer basket for easy sink clean up. Polypropylene housing. Fits standard 3½" opening.

# 4010 Covered Flip Top Disposer Strainer.



Water drains easily when cover is in place. Cover flips up with easy touch. Polypropylene housing. Top mount installation for 3½" opening.

### 2310 Remote Covered Flip Top Sink Strainer.



Turn the remote knob to open and close drain. Water drains easily when cover is in place. Cover flips up with easy touch.

Cover makes a flat surface at the sink bottom that prevents food waste from getting into the strainer basket for easy sink clean up.

Polypropylene housing. Fits standard 3½" opening. 1¾" hole required in countertop for remote installation. Remote cable 25½" L.